



Accessories NOT Included for '55-'56 Chevrolet Tilt

Minimum accessories required if using the original steering box:

| | |
|--|---------|
| Floor Mount I4140 | \$12.00 |
| Coupler: Floor Shift BORC1DDXC7DD | \$38.00 |
| Column Shift BORC736XC7DD | \$38.00 |
| Wiring Adaptor: 1955 Chevy I554K | \$33.50 |
| 1956 Chevy I564K | \$33.50 |

Minimum accessories required if using a 605 Box

| | |
|--|---------|
| Floor Mount I4140 | \$12.00 |
| Rag Joint: Floor Shift BORVRD1DDX730..... | \$90.00 |
| Column Shift BORVRD736X730..... | \$90.00 |
| Wiring Adaptor: 1955 Chevy I554K | \$33.50 |
| 1956 Chevy I564K | \$33.50 |

| | | |
|----------------------------|-------------------------|----------|
| 1957 Chevrolet Tilt | | |
| I1257 | Steel Tilt | \$319.00 |
| I1257C | Chrome Tilt | \$419.00 |
| I0757B | Alum. Tilt Brushed | \$620.00 |
| I0757P | Alum. Tilt Polished | \$620.00 |
| I1457 | Steel Column Shift | \$520.00 |
| I1457C | Chrome Col. Shift | \$650.00 |
| I1557B | Alum. Col. Shift Brush. | \$935.00 |
| I1557 | Alum. Col. Shift Pol. | \$935.00 |

Minimum accessories required if using the original steering box:

| | |
|--|---------|
| Floor Mount I4140..... | \$12.00 |
| Coupler: Floor Shift BORC1DDXC7DD..... | \$38.00 |
| Column Shift BORC736XC7DD..... | \$38.00 |
| Wiring Adaptor I574K..... | \$33.50 |

www.dannysrodshop.net



1-800-335-1932

Minimum accessories required if using a 605 Box:

| | |
|---|---------|
| Floor Mount I4140..... | \$12.00 |
| Rag Joint: Floor Shift BORVRD1DDX730..... | \$90.00 |
| Column Shift BORVRD736X730..... | \$90.00 |
| Wiring Adaptor I574K..... | \$33.50 |

1961-1962 Impala

| | | |
|--------|-----------------------------|----------|
| I1262 | Steel Tilt | \$320.00 |
| I1262C | Chrome Tilt | \$420.00 |
| I0762B | Alum. Tilt Brushed | \$609.00 |
| I0762P | Alum. Tilt Polished | \$609.00 |
| I1462 | Steel Col. Shift | \$520.00 |
| I1462C | Chrome Col. Shift | \$650.00 |
| I1562B | Alum. Col. Shift Brushed | \$935.00 |
| I1562P | Alum. Col. Polished | \$935.00 |

1963-1964 Impala

| | | |
|--------|-----------------------------|----------|
| I1267 | Steel Tilt | \$385.00 |
| I1267C | Chrome Tilt | \$710.00 |
| I0767B | Alum. Tilt Brushed | \$669.00 |
| I0767P | Alum. Tilt Polished | \$669.00 |
| I1467 | Steel Col. Shift | \$585.00 |
| I1467C | Chrome Col. Shift | \$485.00 |
| I1567B | Alum. Col. Shift Brushed | \$999.00 |
| I1567P | Alum. Col. Polished | \$999.00 |

Minimum accessories required for '61-'67 Impala if using original steering components:

| | |
|--|---------|
| U-Joint 3/4" 36 x 3/4" 36 BOR6736X736..... | \$68.00 |
| Shaft Original..... | ----- |
| Rag Joint Original..... | ----- |
| Wiring Adaptor ('61-'62) PARK37616..... | \$33.50 |
| Wiring Adaptor ('63-'64) PARK37618..... | \$33.50 |



Cool Parts For Cool People

Minimum accessories required for '61-'67 Impala if using all NEW steering components:

| | |
|---|---------|
| U-Joint 3/4" DD x 3/4" 36 BOR67DDX736..... | \$68.00 |
| Shaft 3/4" DD x 36" BORS7DDX36..... | \$68.00 |
| Rag Joint (choose one) 3/4" DD x 3/4" 30 BORVRD7DDX730..... | \$90.00 |
| 3/4" DD x 3/4" 36 BORVRD7DDX736..... | \$90.00 |
| Wiring Adaptor ('61-'62) PARK37616..... | \$33.50 |
| Wiring Adaptor ('63-'64) PARK37618..... | \$33.50 |

1965 - 1966 Impala

| | | |
|--------|-----------------------------|----------|
| I1266 | Steel Tilt | \$320.00 |
| I1266C | Chrome Tilt | \$420.00 |
| I0766B | Alum. Tilt Brushed | \$609.00 |
| I0766P | Alum. Tilt Polished | \$609.00 |
| I1466 | Steel Col. Shift | \$520.00 |
| I1466C | Chrome Col. Shift | \$650.00 |
| I1566B | Alum. Col. Shift Brushed | \$935.00 |
| I1566P | Alum. Col. Polished | \$935.00 |

Minimum requirements required if using all NEW steering components.

| | |
|---|---------|
| (Front Steer) | |
| U-Joint 3/4" DD x 3/4" 36 BOR67DDX736..... | \$68.00 |
| Shaft 3/4" DD x 36" BORS7DDX36..... | \$68.00 |
| Rag Joint (choose one): 3/4" DD x 3/4" 30 (manual) BORVRD7DDX730..... | \$90.00 |
| 3/4" DD x 3/4" 36 (manual) BORVRD7DDX736..... | \$90.00 |
| 3/4" DD x 13/16" 36 (power) BORVRD7DDX836..... | \$90.00 |
| Wiring Adaptor PARK37618..... | \$33.50 |

Minimum requirements required if using all NEW steering components.

| | |
|---|---------|
| (Rear Steer) | |
| Rag Joint 3/4" x 36 x 3/4" 30 (manual) BORVRD736X730..... | \$90.00 |
| 3/4" x 36 x 3/4" 36(manual) BORVRD736X736..... | \$90.00 |
| 3/4" x 36 x 13/16" 36 (power) BORVRD736X836..... | \$90.00 |
| Wiring Adaptor PARK37618..... | \$33.50 |

Toll Free order line 1-800-335-1932
Tech/Information line (513) 722-3522