


How To Measure A Steering Column



Note: *Steering Wheel and Adaptor:* Most aftermarket steering wheels will need 2-4" from the gripping surface of the wheel to the top of the outer housing of the steering column. Measure and mark the dowel. This is where the measurement of your steering column will have to be adjusted for comfortably.